

PAPER - PASTE THE SHEET

Hanging Instructions



Keys to a Successful Installation

- Installation by an experienced professional paper hanger is strongly recommended.
- Inspect the wallcoverings after hanging three strips and throughout the installation to see if it meets your expectations. If you notice any problems during the installation, stop hanging and consult your supplier. Claims for labor will not be honored. The Wallcoverings will be considered acceptable once more than three strips of wallcovering have been hung.
- All rolls should be from the same run/batch number.
- Be sure you have enough of all decorative materials before beginning the installation.
- Careful wall preparation is vital to achieve the perfect finish.
- * Use a high-quality wall-liner such as Wallquest® Premium Wall Liner (WL100) before hanging (OPTIONAL)
- Use a high quality pre-mixed, clear adhesive such as ACM Adhesive, Roman® or Bartoline®
- Use a very sharp blade and change the blade frequently to ensure a clean cut.
- Allow wallcoverings to remain on the site for 3 days at normal environmental conditions before installing.

Wall Preparation

Walls must be clean, dry, and free from grease, dirt, mold or and any loose material. Apply a stain killing primer if necessary. Then apply a primer specifically designed for wallcoverings installation and wall protection. Allow primer to dry and seal the walls with wallpaper size. Again, allow the walls to dry completely before proceeding.

*Wall Liner Installation (OPTIONAL)

Install the wall-liner in a horizontal manner. This will help to eliminate any existing imperfections in the wall. It will also ease the removal of the wallcoverings in the future. When the walls are dry, they should be sealed using a wallpaper size.

PASTE THE SHEET INSTRUCTION





1. Cut and hang only one strip at a time. Cut each strip to the height of the wall plus 15 cm (6 in). BE SURE TO ACCOUNT FOR THE MATCH OF THE PATTERN BEFORE CUTTING THE STRIP.
2. Apply a lightweight pre-mixed vinyl adhesive to the wallcovering, carefully following the paste manufacturer's instructions. Please ensure sufficient paste is applied to the edges of the wallcovering.
3. Fold the strip slowly, glue on glue, by taking both ends to the middle of the strip (booking). Let it sit for 3-5 minutes.
4. Start hanging each strip from the top and use a soft brush to smooth it into place. Try to minimize the amount of paste on the face of the wallcoverings during hanging. Low tack painters tape can be used to protect the edge of previously hung adjoining strips from paste.
5. Carefully use your palms to butt the edge of each of the strips together.
6. Gently use a seam roller with a plain piece of paper to ensure that the edges are firmly adhered to the wall. If you apply too much force the roller may leave an indentation in the wallcoverings.
7. Use a sharp blade and a straight edge to line the top and the bottom of the strip.
8. IMPORTANT: If possible, wash adhesive completely from the surface of the wallcovering immediately after hanging each strip. Any adhesive left on the wallcovering can attack the surface printed inks and cause them to flake. The materials are also sensitive to prolonged contact with water. DO NOT ALLOW PASTE TO DRY ON THE SURFACE. DO NOT SCRUB!
9. Once installed, allow the wallcoverings to dry naturally without additional heat or forced drying. Be sure there is adequate ventilation in the room.




Cleaning






Clean using a damp non abrasive sponge or cloth. Do not scrub.





SYMBOL GUIDE

Pattern Match	
Straight Match	
Half Drop	
Reverse Hang	
Random	

Paste Application	
Paste the Wall	
Paste the Paper	
Peelable	

Cleaning Treatment	
Spongeable	
Washable	
Extra Washable	
Scrubbable	
Dry Clean Only	

Removal Method	
Strippable	
Wet Removable	

Light Fastness	
Good Light Fastness	